CRC 707V

English

Instruction For Universal LCD/LED TV Remote Controller

Thank you for using our company remote controller products. When it is the first time to put in the batteries, please try it first. If it could work wel with all of its functions, the product can be used directly without setup. if it could not work well, i should be set with the following methods before controlling your TV. This remote controller would no lose its memory when you change batteries, no need to reset.

Introduction:

CRC 707V is the newest universal LCD/LED TV remote control.Without setup, It's defaulted work for SAMSUNG , SONY , LG directly. Comprehensive care at different levels need, it can also set for different brand or model of TV. Finish setting in 30s . It is the best choice for your remote controller is lose or damaged, it will bring more convenient for your life.



Battery Installation

In accordance with the "+,–" symbols which is indicated inside the battery cabinet, open the cover and put into two new AAA (AAA) batteries (non–rationed), which is shown in the figure.

Battery Description

●The remote controller is a low–power consume product. The lifetime of batteries is about 12 months under normal circumstances. If it is improperly used or operated, the lifetime would be shortened.

●Please do not put old and new batteries or different types of batteries together.

●In case of battery leakage, the batteries must be removed and the battery cabinet should be cleaned before putting into new batteries.

●You'd better remove the batteries from the battery cabinet if you intend to stop using the remote controller for a long time.

Methods for setting remote controller:

This remote controller has the following methods for setup , you can choose any of them.

****

A.Inputting code:

1, Turn on your TV set, let your TV set be in the normal state play, and aim the remote controller in the front of the TV. Find the three digits code from the code list.



2, Press "SET" button, then press "POWER" button, till the indicator lamp lights, then release the buttons, the remote controller will be in the state of inputting code.

3, Enter the first set of three–digit code in order. When you input each digit, the indicator lamp will flash one time, when you enter all of the three digits, the indicator lamp will turn off., setting to be finished. If the code is more than one set, please use first one at first.

4, Test other function buttons can work well or not, such as "MUTE". If not, repeat steps 2 to 3, until you find the suitable code.

B.Manually searching for the code:

1, Turn on your TV set, let your TV set be in the normal state play, and aim the remote controller in the front of the TV.

2, Press "SET" button, then press "POWER" button, till the indicator lamp lights, then release the button, the remote controller will be in the state of Manually searching for the code.

3, Press the "VOLUME+" button one time, the indicator lamp will flash one time, please pay attention to your TV, see the volume symbol appears on your TV or not, if not, please repeat this procedure.

4, Till the volume symbol appears on your TV, test other function buttons(except SET, POWER, and VOLUME button) can work well or not, such as "MUTE". If not, repeat steps 2 to 3, until you find the suitable code.

C.Automatically searching code:

1, Turn on your TV set, let your TV set be in the normal state play, and aim the remote controller in the front of the TV.

2, Press and hold the "SET"button for about 6 seconds, till the indicator lamp lights, the remote controller will enter automatic search state,

please pay attention to your TV, see the volume symbol appears on your TV or not, if yes, please release "SET" button at once, set finished.



3, Test other function buttons (except SET, POWER, and VOLUME button) can work well or not, such as "MUTE". If not, repeat steps 2 to 3, until you find the suitable code.



D.Point to Point Brand Searching:

1, Turn on your TV set, let your TV set be in the normal state play, and aim the remote controller in the front of the TV. Find out the corresponding brand of your TV on this remote control, for example, SKYWORTHY = "0"

Brand symbol table

P.MODE	S.MODE	ASPECT	SLEEP	MENU	SOURCE	1	2	3	4	5	6	7
AKIRA	AOC	BBK	EUROSI	SUPRA	OTHER BRANDS	SHARP	SONY	Panasonic	SANYO	HITACHI	TOSHIBA	PHILIPS
8	9	-/--	0		SYS	GUIDE	TV	RED	GREEN	YELLOW	BLUE	
LG	SAMSUNG	Hisense	SKYWORTH	CHANGHONG	TCL	PRIMA	Haier	KONKA	THOMSON	DAEWOO	JVC	

2, Press and hold the corresponding brand button for three seconds, the indicator lamp will flash, when the volume symbol appears on your TV, release button at once, the indicator lamp will turn off, set to be finished.

E.Restore factory Settings

Press "SET" button, then press "0", release the button, the indicator will flash two times, the remote controller restore factory Settings

****

Русский

А.Поиск нужной марки телевизора с помощью ввода кода вручную

1. Включите телевизор и в перечне кодов найдите тот, который соответствует марке Вашего телевизора.

2,Одновременно нажимайте кнопки "SET" и "POWER", пока не загорится индикаторная лампочка.

3, Введите три первых цифры кода, соответствующего модели телевизора. после ввода кода индикатор перестанет гореть, установка завершена



4, Проверьте работу кнопок на ПДУ. При наличии проблем повторно выполните процедуру настройки, начиная с шага 2.

В. Способ ручного поиска кода:

1. Включите телевизор и направьте на него пульт.

2. Одновременно нажимайте кнопки "SET" и "POWER", пока не загорится индикаторная лампочка.Тогда релиз, на этот раз в состоянии ручного поиска.

3. Нажмите кнопку"громкость+", затем освободите её, когда появится символ громкости, при каждом нажатии индикатор мигает один раз, если не появится символ громкости, повторите операцию.

4. После появления символа громкости проверьте другие кнопки (кроме кнопки настройки, кнопки питания, кнопки громкости). Если другие функции нормальны, нажмите кнопку "настройки", индикатор настройки гасит, настройка выполнена.

С.Модели с функцией автоматического поиска

1, Включите телевизор и направьте на него пульт.

2, Удерживайте нажатой кнопку "SET", пока не загорится индикаторная лампочка. Индикаторная лампочка начнёт мигать. Пульт активизировал функцию автоматического поиска. Внимательно смотрите на экран телевизора, не отпуская кнопку "SET". Введите три первых цифры кода, соответствующего модели телевизора.

3, Проверьте работу кнопок на ПДУ(Установите кнопку, кнопка питания, клавиши регулировки громкости, кроме) . При наличии проблем повторно выполните процедуру настройки, начиная с шага 2.



D.

1, Найдите код, соответствующий модели вашего телевизора. Например, для SKYWORTHY – это «0». Включите телевизор и направьте на него пульт.

Сравнительная таблица символов марки

P.MODE	S.MODE	ASPECT	SLEEP	MENU	SOURCE	1	2	3	4	5	6	7
AKIRA	AOC	BBK	EUROSI	SUPRA	OTHER BRANDS	SHARP	SONY	Panasonic	SANYO	HITACHI	TOSHIBA	PHILIPS
8	9	-/--	0		SYS	GUIDE	TV	RED	GREEN	YELLOW	BLUE	
LG	SAMSUNG	Hisense	SKYWORTH	CHANGHONG	TCL	PRIMA	Haier	KONKA	THOMSON	DAEWOO	JVC	

2, Удерживайте нажатой кнопку кода, пока не загорится индикаторная лампочка (около 3 секунд). Не отпускайте кнопку, и индикаторная лампочка начнёт мигать. Активизировался режим поиска кода. Когда на экране появится символ громкости, отпустите кнопку кода. Индикаторная лампочка погаснет.
Проверьте работу кнопок на ПДУ. При наличии проблем повторно выполните процедуру настройки, начиная с шага 2



****

Español

A.Ingresa el código

1, Encender el televisor , apunte el control remoto hacia televisor. luego encontrar el correspondiente código de tres dígitos de la marca correspondiente en la tabla de códigos

2, Presiona al mismo tiempo el botón SET y POWER , hasta la luz indicador se enciende, luego suelta el botón por lo que se convierte en el estado de entrada de código

3, Ingresar primer conjunto de código de tres dígito. cada vez que un dígito es la entrada, la luz de indicación parpadea una vez, despúes que todos los 3 dígitos ha ingresado , la luz de indicador estaría apagado, si el código es más de un conjunto. por favor, utilice la primera.

4, prueba si otros botones de función podría funcionar bien, como el botón de silencio (mute) si no, repita los pasos 2 hasta que encuentre un conjunto de código adecuado.

B.La búsqueda manual del código

1, Encender el televisor , apunte el control remoto hacia televisor.

2, Presiona al mismo tiempo el botón SET y POWER , hasta la luz indicador se enciende, luego suelta el botón por lo que se convierte en el estado de entrada de código

3, presione el botón de volumen + una vez y luego suéltelo. ver si el símbolo de volumen aparece en la pantalla de TV, si no se produce tal símbolo, repita el procedimiento.

4, Después de que el símbolo de volumen aparece, pruebe otro botón de función (excepto el ajuste(SET), POWER, VULUMEN),si bien el trabajo, pulse el botón de ajuste inmediato y la luz de indicación se apagará , lo que significa que la configuración se ha terminado.

C.La búsqueda automatica del códigos.

1, Encender el televisor , apunte el control remoto hacia televisor.



2 Presione y mantenga el botón de ajuste(SET)durante unos 6 segundos hasta la luz indicador se enciende.
Ver si el símbolo de volumen aparece en la pantalla ,si es así,suelte de inmediato el botón SET para detener la busqueda automatica.



3, pruebe otro botón de función (excepto el ajuste(SET), POWER, VULUMEN),si bien el trabajo, pulse el botón de ajuste inmediato y la luz de indicación se apagará , lo que significa que la configuración se ha terminado. si no, repita los pasos 2 hasta que encuentre el código adecuado.



D.Mode de búsqueda de punto a punto

1, Encender el televisor manualmente, apunte el mando a distancia hacia el televiso , busque la marca correspondiente de TV, tal como SKYWORTHY con su símbolo 0.

La table de symbole correspondant à la marque

P.MODE	S.MODE	ASPECT	SLEEP	MENU	SOURCE	1	2	3	4	5	6	7
AKIRA	AOC	BBK	EUROSI	SUPRA	OTHER BRANDS	SHARP	SONY	Panasonic	SANYO	HITACHI	TOSHIBA	PHILIPS
8	9	-/--	0		SYS	GUIDE	TV	RED	GREEN	YELLOW	BLUE	
LG	SAMSUNG	Hisense	SKYWORTH	CHANGHONG	TCL	PRIMA	Haier	KONKA	THOMSON	DAEWOO	JVC	

2, pulsada botón de símbolo de marco correspondiente,durante unos 3 segundos no suelte el botón hasta que la luz indicador parpadea, Cuando aparece el símbolo de volumen en la pantalla de TV, suelte inmediatamente el botón, y la luz de indicador apagará. Probar si el contro remoto funciona bien , si no, repita el procedimientos.



E.Restaurar los ajustes de fábrica

Pulse el botón "SET", después pulse el número 0, la liberación, el indicador parpadea dos veces, restablecer la configuración de fábrica

****

Warm Tips

If you have any problems when you set or use this remote controller, please try to do as follow:

● When you set this remote controller, please do according to the steps of the method "inputting code". If it can't control your device,
Please input the other codes according to sequence.

● If you have input wrong codes, but the indicator still light, you just need to input the correct code. If the indicator turn off, you need
to reset from step 1.

● whe you use the method "Manually searching for the code", because the codes are too much, you need to wait patiently

Technical parameters

● Remote Controlling Distance: About 8 meters (varies by different types)

● Battery Type: two pieces of AAA Batteries

After-sales Service

If the remote controller has problems or could not be used temporarily, please contact our company as soon as possible. We would make efforts to offer you with best services. But do not disassemble or repair it by yourself. We would not be responsible for remote controllers that have been disassembled without authorization.

To ensure that you could enjoy good after-sales service, please keep the shopping bills or receipts when buying the product.

The Company reserves the final interpretation of this specification. The design and technical parameters could be changed without notice.

CRC 707V

Instruction For Universal LCD/LED TV Remote Controller

000	002	003	004	005	006	010	011	012	013			
AOC AOC	GENERAL LCD-831	GENERAL LCD-832	IZUMI TL19H405B	IZUMI 0152	EN 30303D	HOB301 MYSTERY KT6957 6857	HOB117 AKIRA TC 1860F1	HOB187 GK23J6-C15	HOB279 AKIRALCT-15CHST			

014	015	016	017	018	019	020	021	022	023	024	025	026	027	028	
4-3-2010-002	BBK BBK	BBK EN-31603B	HOB158 BBK LT1504	HOB332 BBK CAMERON	HOB380 RC2465	HOB387 RC-2603	HVD208 BBK	HVD209 RC1529	HOB228 LCD 831	HOB283 SUPRA 4627/STV-LC1504	HOB302 HYUNDAI 1587 RCF1B	HOB303 SUPRA306STV-LC1515	HOB327 Supra RC3b	HOB328 Supra RCF3b	

029	030	031	032	033	034	035	036	037	038	039	040	041	042		
HOB409 SUPRA Y-72C2	HOB410 SUPRA RC6b	HOB411 SUPRA RC12	RCF1B RCF1B	SUPRA BD-212	SUPRA HOF 12H126GPD11	SUPRA RC1b	SUPRA RC5b	SUPRA RC5db	SUPRA RC13b	SUPRA RC-I18-0B	SUPRA STV-LC2615ED	HOB168 SHIVAKI BT0451C	HOB231 SHIVAKI 02		

043	046	047	048	049	050	051	052	053	054	055	056	057	058		
ROLSEN ER-31607R	HTC056 RC1994907-01	HTC058 RC198	H0B333 81E829	H0B394 81E503	H0B227 ORION	H0B252 OPENBOX-1253	H0B281 MYSTERY 5195	H0B282 MYSTERY 8151	H0B301 MYSTERY KT6957 6857	H0B326 MTV-1914LW	MESTERY LCD LED TV NEW	HSR499 HIVION	HOB402 ISTAR		

059	060	061	062	063	066	067	068	069	070	071	073	074	079		
HOB 403 iS TAR	HOB 405 iS TAR	ER-31607	HOB438 ER-31607R-1098#	LCD-2277RC	HOB302 HYUNDAI 1587 RCF1B	HOB376 H-LCD2202GC0VA1028SJ	HOB390 CH-2145	FUSION RC3B-1042	HOB198 FUNAI 48KEY	IR 1628 FUNAIPC221	HOBO18 ELENBERG Y27401	HOBO354 ELENBERG	HOB 151 BERICOM008		

080	081	082	083	084	085	086	087	088	089	090	091	092	093		
HOB189 HOB189	HOB264 RC-A3-01	HOB273 HOB273	HOB373 EN-21662B	HOB223 RC-L-05	HOB225 RC-L-06	HOB108 ACH-P-2	HOB149 BERICOM006	HOB150 BERICOM007	HOB206 EL-41UA299	HOB329 T15E01MT	HOB330 H-LED32V6	HOB341 STV-LC1914W	HOB418 ZD-RC30		

094	095	096	097	098	099	100	101	102	103	104	105	106	107		
DMTECH DMTECH	HOB262 HOB262	HOB344 HOF45A1-2	HOB249 PARS	HOB292 H502-2	HOB013 HOF-54B1.4	HOB339 GIS2138	HOB381 HOF12E148GPD5	HOB346 HOF10G705GPD9	SONIQ QT-112	SUNSTECH TL1970HD	HOB195 H-LCDVD2200	HOB196 HOB196	HOB314 Singer LCDKZG-108		

108	109	110	112	113	114	115	116	117	120	121	122	123	124
HOB386 RM-611	HOB308 IR 1492 SENCOR	HOB310 HOB310	HOB342 STV-LC1985WL	HOB382 GI HOF 12B441GPD11	HOB220-NF021RD NF028RD-NF031RD-NF036RD-4IN1	NF039RD NF039RD	PC221 01	PC221 02	BC10SB BC10SB	daytron LCD TV	HOB358 RC-A03	RC A06	RC A10

125	126	127	130	131	132	133	134	135	136	137	138	139	140
TLCD 32HD-TELEFUNKEN	KAIMY KAIMY	acer acer	HOB162 BERICOM009	HOB187 GK23J6-C15	LCD-2699	HOB229 OPTICUM9600 TS20	HOB242 RC1994925	HOB253 SNOWA	HOB331 AKAI A4001032	HOB353 KM1128	HOB368 S5 S6 S7 S8 S9	LCD-2318	HOD142 HOD142

141	142	143	144	145	146	147	148	149	150	151	152	153	154
HOD148 VT-L9A11	HSR553 CYFROWY POLSAT	HSR585 IPM PLATFORM	Singer LCD TV 901-7650-31SG1G	LCD TV FU-1	LCT 01	LCT 02	148 148	HOB393 1253	12-17-2011_001	AOC-01	AOC-02	BENQ-01	BENQ-02

155	156	157	158	159	160	161	162	163	164	165	166	167	168
BENQ-03	BENQ-04	BENQ-05	VIZIO	NEC RP-42L1	SANYO JXPYR	ROLSEN RL-32L700U	POLYTRON 81f579	SAM_2446	SAM_2443	SAM_2457	LCD TV	AKAI A3001012	AKAI CX-507

169	170	171	348	349	350	351	352	353	354	355	356	357	358
BBK EN-31907	CHANGHONG GHK-4421A	E-RCU-015	BBK_EN-31907	Benq	china	EcoStar 2	HCH067-CGANGHONG GHK-4421A	Heir2	HOB477 AKAI CX-507	HOB478 E-RCU-015	HOB479 AKAI A3001012	HOB484 Akai LTA-15A15M	HOB489 MESTERY LCD LEDTVNEW

359	360	361	362	363	364	365	366	367	368	370	371	372	373
HOB490 Polar HTR-D18A	HOB491 Polar 55LTV6002	Orient	PROTON 2	POLYTRON EN-31618P 81E878	HOB864 SNOWA T202-1	HOB455 ELECTRON T-81100	HOB457 RL-32L700U 3D	HOB464 BRAVIS LED 2868 HQ	HOB465 DIGITAL DLE -4011	HOB46 LUXEON LED3213 HQ	ORION EP 22 LCD 2623	HOB493 HAIER	HOB494 SUPRA

374	375	376	377	378	379	380	381	382	383	384	385	386	387
HOB498 SHOWNIC	LEA-19V07P	IZUMI	81F579	ORION OR-LCD2	FUSION RC21b	SUPRA RC6w	SUPRA RC8b	SUPRA RC10w	SUPRA RC18b	RC-LEM100	BBK RC-LEM101	BBK RC-LEM100	IZUMI_TL26H211B

388	389	390	391	396	397	398	399	400	401	402	403	405	406
JAC	SKY LINE	TRUMAN	union tech	ATLAS HD100	HOB688 ATLSS HD-200S	KK-Y331J	KK-Y331J	HD LED100	GB TY ONGOV59	XY-B02E	LCD TV PHONAR	PHONAR LED TV	DAWA MV

407	408	409	410	411	412	413	414	415	401	417	418	419	420
iDEA	iDEA	iDEA	iDEA	iDEA	iDEA	iDEA	iDEA	A0C-02	DEX LT-2220	ORION LED2643	Akai SLP-006P	Fusio FLTV 22H11	Fusio FLTV 33H17

421	422	423	424	426	427	428	429	430	431	432	433	434	435
FUSION RC15b	Shivaki k77	Shivaki k78	Supra TV-DVD	RC-GK22G1	H-LCD3210	LED321LC	SKYPRIME HD	SUPRA RC21b-1219	ORION LCD	TC 1860F1-RS	JH-11370	LED-851	RC-D3

436	437	438	439	440	441	442	442	442	442	443	444	445	446
YC-53	STV-22LED5	LED-EH4720BF	DNS M28AM8	051D RED	33585	RC33729	HOB842	34090	34091	RC31277	Fusion RC25b	RCF23b	RC-E23

449	450	451	452	453	454	516	520	528	531	540	542	500	544
AKI AK61	AKILCD AK66	AKILCD AK68	AKI-OND IGO LCD	ONIDA LCD	ONIDA LCD ON87	O51D BLACK	SNOWA51163	BLAUPUNKT	J-1274	MERTER33186	BRAVIS IFD-1615	STV-42LED5	ONIDA LCD1

545	546	547	548	549	540	540	550	551	533
Akai HOF08J001	Polar 94L TV6004	AN-LT3222 AN-LT3225 AN-LT2416	FUSION HY-079	SATURN LED40FHD500U	DEXP 16A3000	RUBIN RB-28D7T2C	DNS S19ASL1	RM-NST60	RM-SK09